



NOTES:

1. PREPARE FRAME FOR SWITCH:
 - A. PREPARE FRAME FOR MORTISE INSTALLATION OF GRI NO. 229. SWITCH SHALL BE INSTALLED IN THE HEADER, 2" FROM THE LOCK STILE EDGE.
 - B. WIRE AND INSTALL SWITCH.
2. PREPARE DOOR FOR MAGNET.

TYPICAL RECESSED DOOR CONTACT INSTALLATION

NOT TO SCALE